





• FDH8 Series Installation  
• Splitter Installation & Routing


## SPLITTER INSTALLATION AND ROUTING




1. Install splitters from edge to center. Insert splitter by pushing it against mounting support until it snaps in.



3. Connect splitter leg to desired adapter on distribution field and route cable on provided management clips as needed.



2. Connect splitter input legs to desired adapters on input area and route cable using the provided management clips as needed.



4. Store unused splitter legs using the provided management clips as indicated below.